



## Varied Monodisperse Oil or Liquid Crystal Emulsion Droplets for Improved Nanoviewing, Sensing and Biosensors

[View U.S. Patent No. 9,012,569 in PDF format.](#)

**WARF: P08136US**

Inventors: Nicholas Abbott, Frank Caruso, Jugal Gupta, Sri Sivakumar

**The Wisconsin Alumni Research Foundation (WARF) is seeking commercial partners interested in developing methods for producing oil emulsion droplets, including monodisperse liquid crystal emulsion droplets, with uniform, predetermined sizes.**

### Overview

Controlled micrometer-scale oil droplets have applications in nano-materials, meso-materials, responsive materials, optical materials, filters, sensors and opto-electronic technologies. Emulsion droplets can be prepared by various techniques. However, most approaches result in polydisperse emulsions, emulsion droplets with limited control over size or interfacial properties, or the formation of polymerized droplets. New techniques that enable the production of large quantities of oil emulsion droplets with controlled properties are needed.

Liquid crystal materials are promising candidates for many sensing and interfacial applications. Liquid crystals respond to and amplify small changes in temperature, electric or magnetic fields, shear or structure at the interface where they contact another material. They serve as “molecular magnifying glasses,” allowing events that occur at the nanoscale to be observed by the naked eye. If liquid crystals could be formed as monodisperse droplet emulsions with finely controlled size and surface chemistry, it could enable new sensing and interfacial technologies, including new types of biosensors.

### The Invention

UW-Madison researchers have developed a versatile, scalable and highly parallel method of producing monodisperse emulsion droplets in a range of predetermined sizes. The oil emulsion droplets, in which the oils can be liquid crystal molecules, can be prepared with or without polymeric shells or capsules.

This method is based on templating polyelectrolyte multilayer (PEM) capsules formed by the layer-by-layer adsorption of polyelectrolytes on sacrificial particles. A polymeric shell is formed around a sacrificial particle, such as silica. Then the silica is etched away and the shell is infiltrated with an oil. The shell then can be removed to reveal monodisperse oil or liquid crystal emulsion droplets of a uniform, predetermined size. These droplets could be used as biosensors to detect enzymatic activity or target analytes, such as bacteria or viruses, in a sample.

### Applications

- Liquid crystal droplet-based biosensors for the detection of analytes, such as bacteria or viruses, in a sample
- New types of liquid crystal compositions, including monodisperse solutions
- Multilayer-coated oil emulsion droplets with functionalized surfaces for sensor and opto-electronic technologies

We use cookies on this site to enhance your experience and improve our marketing efforts. By continuing to browse without changing your browser settings to block or delete cookies, you agree to the storing of cookies and related technologies on your device. [See our privacy policy.](#)

### Key Benefits

OK



**WARF**  
Wisconsin Alumni Research Foundation

| [info@warf.org](mailto:info@warf.org) | 608.960.9850

- Rapid, parallel and scalable, enabling the preparation of large quantities of emulsion droplets
- Provides the ability to readily prepare monodisperse droplets in a wide range of sizes, as capsule templates can be prepared with diameters as small as 50 nanometers and as large as millimeters
- Droplet shape may be controlled through the use of non-spherical sacrificial particles.
- Allows preparation of emulsion droplets of different compositions with well-defined surface functionality
- Granulometric distribution of droplets may be less than 10 percent.

## Stage of Development

This method has been demonstrated with liquid crystals and silicon, paraffin and cooking oils.

### Publications

- Sivakumar S., Wark K.L., Gupta J.K., Abbott N.L. and Caruso F. 2009. Liquid Crystal Emulsions as the Basis of Biological Sensors for the Optical Detection of Bacteria and Viruses. *Adv. Funct. Mater.* 19, 2260-2265.
- Gupta J.K., Sivakumar S., Caruso F. and Abbott N.L. 2009. Size-Dependent Ordering of Liquid Crystals Observed in Polymeric Capsules with Micrometer and Smaller Diameters. *Angew. Chem. Int. Ed.* 48, 1652.

### Tech Fields

- [Analytical Instrumentation, Methods & Materials : Sensors](#)
- [Research Tools : Detection](#)

For current licensing status, please contact Jennifer Gottwald at [jennifer@warf.org](mailto:jennifer@warf.org) or 608-960-9854

We use cookies on this site to enhance your experience and improve our marketing efforts. By continuing to browse without changing your browser settings to block or delete cookies, you agree to the storing of cookies and related technologies on your device. [See our privacy policy.](#)

OK



**WARF**  
Wisconsin Alumni Research Foundation

| [info@warf.org](mailto:info@warf.org) | 608.960.9850